





Installation of the EC-Unobox with axial air direction.
Mounting hardware is **not** included!

Indoor installation:



Outdoor installation:



Another possible accessories:



BT
Service door



SV
Side covering



GS
ON/OFF-switch



POT 1
Control unit
(stepless)



POT 2
Control unit
(stepless)



POT 3
Control unit
(3-step)



MTC
Control unit
(0-10V)